

ECS4120 Series Notice

HARDWARE COMPATIBILITY:

- ECS4120-28F-I must use runtime **v1.0.2.17** and above.
- ECS4120-28Fv2 must use runtime **v1.0.2.24** and above.
- ECS4120-28Fv2-I must use runtime **v1.0.2.31** and above.

The other models are not necessary to use the specific version.

Please **DO NOT downgrade** to not support runtime version, or you may fail to bootup the switch.

If you have any problem, please contact with Edgecore Technical Support Team for help:
support@edge-core.com